

## INSTALLATION INSTRUCTIONS:

- 1. REMOVE DO3 VALVE AND O-RINGS, DISCARD EXISTING SCREWS.
- 2. POSITION DO3 TAPPING PLATE MAKING SURE THAT ORIFICE PLUG IS INSTALLED ON P PORT HOLE AND O-RINGS SUPPLIED WITH TAPPING PLATE ARE IN POSITION (NOTE ORIENTATION OF TAPPING PLATE PIN).
- 3. REINSTALL DO3 VALVE USING AND O-RINGS WITH SUPPLIED SCREWS, TORQUE TO 44-62 IN/LB.
- 4. REPEAT ABOVE STEPS FOR REMAINING PROPEL SECTION.



NO.	QTY	DESCRIPTION	PART NO.
1	REF	PLATE, DO3 TAPPING	319089
2	REF	SCR, SOC: M5-0.8 X 50	501191

## TOP VIEW



REV	EN	DESCRIPTION	DATE	DRN
1	3153	NEW RELEASE	5-18	PJP
2	3280	DEL 473513 318839, ADD 319089	7-18	PJP

## DIMENSION TOLERANCES UNLESS OTHERWISE SPECIFIED

ANCIII AR Y°-+1° Y Y°-+ 5°	LINEAR	.XX=±.03	.XXX=±.010	
ANGULAN X - I X.X - I.J	ANGULAR	X°=±1°	X.X°=±.5°	

SURFACE FINISH 125/ SMOOTH ALL SHARP EDGES CLEAN ALL WELDS

THIS PRINT AND ALL INFORMATION WITHIN BELONGS TO RACINE RAILROAD PRODUCTS

## RACINE RAILROAD PRODUCTS RACINE, WISCONSIN USA

DESCRIPTION

INSTRUCTIONS, PROPEL SOFT START

MATERIAL

SEE BOM

USED ON				SCALE	DA	TE
	79302	24		1:4	0	5-14-18
DRN	CHK	APP	JO	B NO		SHEET
PP						1 OF 1
EXP NO		-	DW	G NO		_
					8	00284