N	D. QTY	DESCRIPTION	PART NO.
1	REF	PLACARD, FASTENER TORQUE	473292
2	2 REF	SCR, DRIVE: #4 X .25	491673


DWG NO


800276

INSTRUCTIONS:

1. LOCATE PLACARDS AS SHOWN, WITH A #37 (.104) DRILL BIT, TRANSFER HOLES THROUGH PLACARDS 3/8" DEEP AND INSTALL DRIVE SCREWS.

2. REPEAT ON OPPOSITE WORKHEAD.





REV	EN		DES	SCR	IPTION	DATE	DRN				
1	3082	NEW R	ELEASE	_		4-18	MSO				
DIMENSION TOLERANCES UNLESS OTHERWISE SPECIFIED											
LI	NEAR	.XX	<=±.0	3	.XXX=±.010						
AN	GULAR	X	$X^{\circ} = \pm 1^{\circ}$		X.X°=±.5°						
SURFACE FINISH 125 SMOOTH ALL SHARP EDGES NOT TO EXCEED CLEAN ALL WELDS											
THIS PRINT AND ALL INFORMATION WITHIN BELONGS TO RACINE RAILROAD PRODUCTS											
RACINE RAILROAD PRODUCTS Racine, Wisconsin Usa											
DESCRIPTION											
INSTRUCTIONS, FASTENER TORQUE PLACARDS (DAA)											
MATERIAL SEE BOM											
USED ON SCALE DATE 1:4 04-19-18											
DRN MS	0.	łΚ	APP		JOB NO RD140001	SHEET 1 OF	1				
EXP	NO			DWG NO							
				800276							