

## **Dual Anchor Spreader**

INNOVATIVE DESIGNS FROM RACINE RAILROAD PRODUCTS



#### **RRP** Design

The Dual Anchor Spreader can spread all types of rail anchors used in a wood tie replacement crew.

Rail anchors do not have to be removed and reapplied during wood tie replacement operations when used in conjunction with the RRP Dual Anchor Adjuster, allowing for increased productivity and longer rail anchor life.

## Innovative Technology

- Programmable MD4 controlled automation has faster & smoother cycle times than previous RRP machines.
- Onboard electrical system diagnostics that simplify troubleshooting and lessen downtime.
- Remote program updates and remote troubleshooting with built-in telematics available.

#### Easy Set-up and Operation

- Easy touchscreen controls for workhead adjustments are made inside the cab from the operator seat, saving time while keeping the operator in a safe environment.
- Auto and Manual operation modes.
- Reliable workhead design provides years of trouble-free service.

#### Versatile

- In-cab adjustments align the workhead to accommodate rail height.
- Easy access to optional tools ensures a quick changeout for either 5", 5 1/2", or 6" rails on all anchor types throughout the head's 15" range.
- Spread two anchors on one rail or four anchors on two rails.
- Many components are interchangeable with the Dual Anchor Adjuster [DAA].

#### Video of the Dual Anchor Spreader: https://tinyurl.com/yc2jjku7





Visit our website: www.racinerailroad.com



# **Dual Anchor Spreader**

INNOVATIVE DESIGNS FROM RACINE RAILROAD PRODUCTS



## **Specifications**

- Dimensions: 22'7" L x 8'5" W x 10'2" H
- Weight: 19,00 lbs
- Travel Speed: 25 MPH
- Engine: We offer a variety of engine packages to choose from, No DEF
- Fuel Capacity: 50 Gallons
- Hydraulic Reservoir: 58 Gallons (Case Drain Filter, Pressure Filter, & Return Filter options available)
- 24 volt system with circuit breakers for lights & accessories
- Seating Capacity: I operator & 2 passengers

#### **Features**

- Excellent visibility of the work zone, increasing productivity and reducing wear on machine travel components.
- Machine has un-obstructed operator visibility fore and aft when track traveling.
- Cab: Enclosed Heat & A/C, full ergonomic seat with joystick controls, tinted safety glass for operator comfort.
- Various HVAC options to choose from.
- Multiple storage options for tools & equipment
- Two joystick controls to control each side of the workhead independently.
- Center H-Frame turntable that sets on the rails to manually rotate the machine as needed.
- Easy accessibility to workhead components to perform routine maintenance.

Config	MACHINE MODE	WORKHEAD AUTO RELEASE	MANUAL AIR LATCH
	Travel Mode	Release Left	Release Left
Mid	Work Mode	Release Right	Release Right
owered	JOYSTICK MODE		
	Dual Trigger		
	Single Trigger		
	Single Trigger		

Operator Touchscreen Control Panel for Workhead Adjustment and Diagnostic Troubleshooting

For a complete list of specifications and machine options available, contact Racine Railroad Products, Inc. at: Tel (262) 637-9681 / email: custserv@racinerailroad.com 1955 Norwood Court Mount Pleasant, Wisconsin 53403

