

Service Bulletin

Maintenance of Way Equipment

Date: 07.21.2020

RRP Service Bulletin No: RRP SB354

Title: Disable Seat Switch Jumper

Rating:



ALERT
 (Potential Problem)



INFORMATION
 (Action Is Optional)



DIRECTIVE
 (Action Is Required)



PRODUCT IMPROVEMENT
 (Enhance Product)

Product Series: Nipper Clipper [NC] & Safelok Clip Remover [SCR]

Serial No:

NC-002-14	913559-UP14	PCAR-1401
NC-003-14	913559-UP14	PCAR-1402
NC-004-14	913559-UP14	PCAR-1403
NC-005-15	913559-UP15	PCAR-1501
NC-006-15	913559-UP15	PCAR-1502
NC-007-16	913576-UP16	PCAR-1601
NC-008-16	913576-UP16	PCAR-1602
NC-009-16	913576-UP16	PCAR-1603

NC-010-16	913576-UP16	PCAR-1604
NC-011-16	913576-UP16	PCAR-1605
NC-012-16	913576-UP16	PCAR-1606
NC-013-16	913576-UP16	PCAR-1607
NC-014-16	913576-UP16	PCAR-1608
NC-021-17	913576	PCAR-1701
NC-022-17	913576	PCAR-1702

SCR-001-16	913577-UP16	PCR-1601
SCR-002-16	913577-UP16	PCR-1602
SCR-003-16	913577-UP16	PCR-1603
SCR-004-16	913577-UP16	PCR-1604
SCR-005-16	913577-UP16	PCR-1605
SCR-006-16	913577-UP16	PCR-1606

Summary: This service bulletin is to remove the seat switch on the PCAR and PCR (NC and SCR) series machines that have a mushroom disable switch.

Action: Unplug switch at control box Connector 65 and install jumper RRP# 715669.

Completion / Resolution: Continue normal machine operation after installation of the jumper.

Instructions

1. Turn the ignition switch to the OFF position.
2. Turn the battery disconnect switch to the OFF position.
3. On the Right Control Box, unplug the switch at Connector 65 and install jumper RRP# 715669.

